

ITEM	PART NO.	DESCRIPTION	QTY.
1	101002-16	STARTER PLATE CRANK MOUNT FIXED 6 INCH	1
2	101303-09	ENGINE JAW 6 HOLE	1
3	101303-75	ENGINE JAW SPACER 1.25	1
4	202006-03	STRUTS CRANK SUPPORT 392 417	1
5	202035-40	STAND CRANK SUPPORT 5.5	4
6	202035-88	BRACE CRANK SUPPORT STAND RIGHT	1
7	202035-89	BRACE CRANK SUPPORT STAND LEFT	1
8	352503-06	3/8 AN WASHER	6
9	352505-49	WASHER HEAT TREATED .316 I.D. .125 THICK .75 DIA	6
10	352505-50	WASHER HEAT TREATED 0.38 I.D. 0.125 THICK 0.90 DIA	8
11	354812-12	SPACER STRAIGHT .75 LONG .312 HOLE 0.6 DIAMETER	6
12	356237-32	3/8-24 X 2.0 12PT	6
13	356331-48	5/16-18 X 3.0 12PT	6
14	356337-16	3/8-16 X 1.0 12PT	10
15	356337-24	3/8-16 X 1.50 12PT	4
16	356925-08	FHCS 1/4-20 X .50	8

*4 when using RCD gear drive and short hub stands should be 4.25" long and 6 spacers # 354812-12 are not needed

