


ITEM	PART NO.	DESCRIPTION	QTY.
1	101303-09	ENGINE JAW 6 HOLE	1
2	101002-16	STARTER PLATE CRANK MOUNT FIXED 6 INCH	1
3	352503-06	3/8 AN WASHER	6
4	352505-50	WASHER HT .38 ID .125 THICK .90 DIA	4
5	356237-40	3/8-24 X 2.50 12PT	6
6	356337-16	3/8-16 X 1.0 12PT	10
7	202022-20	POINTER RCD FRONT COVER ADJUSTABLE 14 DEG	1
8	357725-10	HHB 1/4-20 x .625	1
9	352503-04	1/4 AN WASHER	1
10	356937-24	FHCS 3/8-16 X 1.50	4
11	101303-75	ENGINE JAW SPACER 1.25	1
12	202035-89	BRACE CRANK SUPPORT STAND LEFT	1
13	202035-88	BRACE CRANK SUPPORT STAND RIGHT	1
14	356925-08	FHCS 1/4-20 X .50	8
15	202035-20	STAND CRANK SUPPORT 4.25	4
16	352503-07	7/16 AN WASHER	4
17	356343-16	7/16-14 X 1.00 12PT	4
18	202007-10	481X CRANK TRIG BRK W-CRANK SUPPORT WING LEFT	1
19	202007-09	481X CRANK TRIG BRK W-CRANK SUPPORT WING RIGHT	1



FIXED CRANK STARTER DRIVE 6IN BLOWN 481X