



ITEM	PART NO.	DESCRIPTION	QTY.
1	101502-01	HAND WHEEL HUB	1
2	101502-03	HAND WHEEL	1
3	101520-03	FIELD HOUSING RCD 1	1
4	101520-07	END BELL AND BRUSH RIGGING	1
5	101520-09	ARMATURE SHAFT THREADED EXTENTION	1
6	101520-13	BEARING RETAINER INNER REAR RCD 1 ARMATURE	1
7	101520-14	BEARING RETAINER OUTER REAR RCD 1 ARMATURE	1
8	101520-15	BRUSH COVER RCD 1 STARTER	1
9	101520-18	BRUSH SET RCD1 STARTER (1 set = 8pcs)	8
10	101520-25	ARMATURE RCD 1	1
11	351550-25	025 "O" RING 0.70 X 1.187	1
12	356810-10	FHCS 10-32 X .625	3
13	352503-05	5/16 AN WASHER	2
14	355231-60	JAM NUT 5/16-18 HEX	2
15	352503-04	1/4 AN WASHER	2
16	350524-02	60 BALL BRG 15 x 32 x 9	1
17	101520-11	RCD1 MOTOR TO RCD GEARHEAD ADAPTOR	1
18	350525-02	62 BALL BRG 15 x 35 x 11	1
19	102510-55	REAR FOOT FOR STARTER	1
20	356899-04	FHCS M5 X 16MM	2
21	352507-05	5/16 LOCK WASHER	2



ENGINEERING INCORPORATED
TEL: 530-292-3133 - FAX: 530-292-3738

MOTOR ASSEMBLY RCD 1-RCD GEARHEAD